

SCREEN-CHEM DEGREASER

Code: AM100037



PRODUCT DESCRIPTION

Concentrated degreaser indicated for the cleansing and cleaning of the meshes before the application of the photo-emulsion.

GENERAL & TECHNICAL FEATURES

- Suitable for both polyester and nylon meshes
- High cleansing power
- Risk labelling free

PREPARATION

SCREEN-CHEM DEGREASER must be diluted with water in a maximum ratio of 1:10.

APPLICATION

Rinse the screen well with warm water then apply **SCREEN-CHEM DEGREASER** through a sponge onto both sides of the screen. Let the product act for few minutes and then rinse off the screen abundantly with water. Dry carefully the screen before applying the emulsion. We suggest to avoid the product dry onto the screen since this oversight could weaken the mesh elasticity.

SHELF-LIFE

If stored in its original container at a temperature of maximum 20°C it will preserve its features for about 2 years from the date of production.



Tel. + 39 031 931923
www.amexsrl.com

Amex srl gives the a/m suggestions as guidelines for the customer and assumes no liability direct or indirect for any improper use. It is the user's responsibility to determine the suitability of the product to the intended use according to working conditions.